

Port RJ45

Reste à configurer


PC client Leger

PC client Lourd

Ligne 4500

192.168.10.xxx

Masque : 255.255.255.0



Ligne 8000

192.168.11.xxx

Masque : 255.255.255.0

